

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2006 CHEVROLET Matiz / Spark (M200) OEM Service and Repair Workshop Manual

[Go to manual page](#)

Folding Top Position	
Switch	Parameter
Folding Top Stowage Compartment Lid Fully Closed Position Sensor	On
Folding Top Open/Close	On
Compartment Lid Partially Closed	
Folding Top Luggage Barrier Sensor	On
Right Folding Top Header Latched Sensor	On
Left Folding Top Header Latched Sensor	On
Left Folding Top Header Unlatched Position Sensor	OFF
Right Folding Top Header Unlatched Position Sensor	On
Folding Top Up Position Sensor	OFF
Folding Top Down Position Sensor	On
Folding Top Tension Bow Up Sensor	OFF
Folding Top Tension Bow Down Position Sensor.	On
Folding Top Stowage Compartment Lid Open Position Sensor	On
Folding Top Stowage Compartment Lid Fully Closed Position Sensor	On
Folding Top Open/Close	On
Top Fully Open	
Folding Top Luggage Barrier Sensor	On
Right Folding Top Header Latched Sensor	On
Left Folding Top Header Latched Sensor	On

Switch Operation For Top Closing

Folding Top Position	
Switch	Parameter
Compartment Lid Partially Opened	
Folding Top Luggage Barrier Sensor	On
Right Folding Top Header Latched Sensor	On
Left Folding Top Header Latched Sensor	On
Left Folding Top Header Unlatched Position Sensor	OFF
Right Folding Top Header Unlatched Position Sensor	On
Folding Top Up Position Sensor	OFF
Folding Top Down Position Sensor	On
Folding Top Tension Bow Up Sensor	OFF
Folding Top Tension Bow Down Position Sensor.	On
Folding Top Stowage Compartment Lid Open Position Sensor	On
Folding Top Stowage Compartment Lid Fully Closed Position Sensor	On
Folding Top Open/Close	On
Top Open/Compartment Lid Open	
Folding Top Luggage Barrier Sensor	On
Right Folding Top Header Latched Sensor	On
Left Folding Top Header Latched Sensor	On
Left Folding Top Header Unlatched Position Sensor	OFF

Folding Top Position	
Switch	Parameter
Folding Top Stowage Compartment Lid Fully Closed Position Sensor	On
Folding Top Open/Close	On
Header Latched/Tension Bow UP/Compartment Lid Open	
Folding Top Luggage Barrier Sensor	On
Right Folding Top Header Latched Sensor	On
Left Folding Top Header Latched Sensor	On
Left Folding Top Header Unlatched Position Sensor	OFF
Right Folding Top Header Unlatched Position Sensor	On
Folding Top Up Position Sensor	OFF
Folding Top Down Position Sensor	On
Folding Top Tension Bow Up Sensor	OFF
Folding Top Tension Bow Down Position Sensor.	On
Folding Top Stowage Compartment Lid Open Position Sensor	On
Folding Top Stowage Compartment Lid Fully Closed Position Sensor	On
Folding Top Open/Close	On
Header Latched/Tension Bow UP/Compartment Lid Partially Closed	
Folding Top Luggage Barrier Sensor	On
Right Folding Top Header Latched Sensor	On
Left Folding Top Header Latched Sensor	On

Folding Top Position	
Switch	Parameter
Folding Top Stowage Compartment Lid Open Position Sensor	On
Folding Top Stowage Compartment Lid Fully Closed Position Sensor	On
Folding Top Open/Close	On
Fully Closed	
Folding Top Luggage Barrier Sensor	On
Right Folding Top Header Latched Sensor	On
Left Folding Top Header Latched Sensor	On
Left Folding Top Header Unlatched Position Sensor	On
Right Folding Top Header Unlatched Position Sensor	On
Folding Top Up Position Sensor	On
Folding Top Down Position Sensor	On
Folding Top Tension Bow Up Sensor	OFF
Folding Top Tension Bow Down Position Sensor.	On
Folding Top Stowage Compartment Lid Open Position Sensor	OFF
Folding Top Stowage Compartment Lid Fully Closed Position Sensor	On
Folding Top Open/Close	OFF

System Protection Functions

Normal operation of the folding top system may be altered by one of the following events.

Obstacle Detection (aka: Blockage Detection)