

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2006 CHEVROLET Tacuma/Rezzo OEM Service and Repair Workshop Manual

[Go to manual page](#)

CAV_4 4

7086 Roof Door Module Driver Door Window Regulator Signal

7086_OG 7086 OG

CAV_8 8

7087 Roof Door Module Pump Valve Manifold Roof Door Module Valve 1

CAV_1 1

7091 Power Roof Module Roof Door Module Pump Valve 2

2250 Ground

CAV_2 2

CAV_1 1

CAV_1 1

CAV_2 2

1150 Ground

1150_BK 1150 BK

CAV_5 5

440 Battery Positive Voltage

842_BN 842 BN

CAV_2 2

CAV_2 2

842 Battery Positive Voltage

842_OG 842 OG

400 Vehicle Speed Sensor Signal

842_WH/L-BU 842 WH/L-BU

CAV_2 2

CAV_5 5

CAV_6 6

7088 Roof Door Module Pass Door Window Regulator Signal

7088_RD 7088 RD

CAV_6 6

CONN_X1 X1

CAV_2 2

CAV_4 4

CONN_X1 X1

1150_BK 1150 BK

842_RD/VT 842 RD/VT

7086_BK 7086 BK

7088_RD 7088 RD

[Master Electrical Component List](#)

[Power Folding Top Description and Operation](#)

[Control Module References](#)

[Folding Top Sensors](#)

1150_BK/WH 1150 BK/WH

CAV_1 1

X402 X402

[Folding Top Harness Routing](#)

[X402 Folding Top Harness to Folding Top Pump Motor Harness \(CM8\)](#)

CAV_1 1

CAV_2 2

G301 G301

[G301](#)

[G301, G304](#)

F2BA F2BA 60A

[B+ Bus \(1 of 2\)](#)

[F2BA, F3BA, F1RA, F5RA, F12RA, F15RA, F16RA, F21RA, F24RA, F30RA, F32RA, and F34RA Fuses](#)

[X50D Fuse Block - Battery Top View](#)

J416 J416

[Folding Top Harness Routing](#)

J415 J415

K23 Folding Top Control Module X1 (CM8)

K23 Folding Top Control Module X2 (CM8)

K23 Folding Top Control Module X3 (CM8)

X50D X50D Fuse Block - Battery

Middle of Luggage Compartment Components

X50D Fuse Block - Battery X2

X50D Fuse Block - Battery X3

X50D Fuse Block - Battery X4

X50D Fuse Block - Battery X6

Q16C Q16C Folding Top Solenoid Valve 3 (CM8)

Folding Top Components (1 of 3) (CM8)

Q16C Folding Top Solenoid Valve 3 (CM8)

Q16D Q16D Folding Top Solenoid Valve 4 (CM8)

Folding Top Components (1 of 3) (CM8)

Q16D Folding Top Solenoid Valve 4 (CM8)

G11 G11 Folding Top Pump Motor Assembly (CM8)

KR149A KR149A Folding Top Pump Motor Relay 1

Folding Top Number 5 Bow Screw	10 N·m (89 lb in)
Folding Top Outside Bow Screw	7.5 N·m (66 lb in)
Folding Top Pivot Bracket Bolt	22 N·m (16 lb ft)
Folding Top Pump Bracket Nut	22 N·m (12 lb ft)
Folding Top Pump Manifold Plate Bolt	10 N·m (89 lb in)
Folding Top Side Rail Bracket Bolt	22 N·m (16 lb ft)
Folding Top Side Rail Bracket Screw	22 N·m (16 lb ft)
Folding Top Stowage Compartment Bracket Nut	9 N·m (80 lb in)
Folding Top Stowage Compartment Extension Outer Panel Screw	4 N·m (35 lb in)
Folding Top Stowage Compartment Lid Hinge Bolt	32 N·m (24 lb ft)
Folding Top Stowage Compartment Lid Nut	22 N·m (16 lb ft)
Folding Top Stowage Compartment Lid Panel Insert Nut	6 N·m (53 lb in)
Reservoir Filler Plug	2 N·m (18 lb in)
Roof Retractable Center Panel Weatherstrip Screw	7.5 N·m (66 lb in)
Roof Retractable Front Panel Side Weatherstrip Screw	7.5 N·m (66 lb in)
Roof Retractable Position Sensor Screw	2 N·m (18 lb in)
Roof Retractable Rear Panel Weatherstrip Screw	7.5 N·m (66 lb in)