

# Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

## 2007 CHEVROLET Tahoe OEM Service and Repair Workshop Manual

[Go to manual page](#)

**CAV\_5** 5

**CONN\_X3** X3

**283** Driver Seat Rear Vertical Motor Down Control

**283\_GY/L-BU** 283 GY/L-BU

**CAV\_3** 3

**CAV\_6** 6

**3298\_WH/RD** 3298 WH/RD

**CAV\_4** 4

**569** Seat Horizontal Motor Position Sensor Signal

**569\_L-GN** 569 L-GN

**CAV\_2** 2

**CAV\_11** 11

**285** Driver Seat Horizontal Motor Forward Control

**285\_YE/L-BU** 285 YE/L-BU

**CAV\_1** 1

**CAV\_11** 11

**CONN\_X3** X3

**284** Driver Seat Horizontal Motor Rearward Control

**284\_GY/L-GN** 284 GY/L-GN

**CAV\_3** 3

**CAV\_12** 12

**3298\_WH/RD** 3298 WH/RD

**CAV\_2** 2

**570** Driver Seat Recline Motor Position Sensor Signal

**570\_WH/BK** 570 WH/BK

**CAV\_4** 4

**CAV\_26** 26

**CONN\_X5** X5

**276** Driver Seat Recline Motor Forward Control

**CAV\_8** 8

**CAV\_10** 10

**CAV\_3** 3

**CAV\_7** 7

**CAV\_4** 4

**CAV\_9** 9

**AAB** MEMORY-DRIVER CONVENIENCE PACKAGE

[Schematics RPO Code List](#)

**AAB** MEMORY-DRIVER CONVENIENCE PACKAGE

[Schematics RPO Code List](#)

**1150** Ground

**1150\_BK** 1150 BK

**CAV\_12** 12

**CONN\_X5** X5

**CAV\_7** 7

**CONN\_X5** X5

**CAV\_8** 8

**CAV\_9** 9

**CAV\_10** 10

**CAV\_19** 19

**CAV\_20** 20

**CAV\_21** 21

**CAV\_22** 22

**3298\_WH/RD** 3298 WH/RD

**570\_WH/BK** 570 WH/BK

**276\_GN/YE** 276 GN/YE

**277\_BU/YE** 277 BU/YE

**CAV\_6** 6

**CONN\_X1** X1

M51D Seat Horizontal Motor - Driver

**M55D** M55D Seat Rear Vertical Motor - Driver

Driver Seat Components

M55D Seat Rear Vertical Motor - Driver

**M56D** M56D Seat Recline Motor - Driver

Driver Seat Back Components

M56D Seat Recline Motor - Driver

**S64D** S64D Seat Adjuster Switch - Driver

Driver Seat Components

S64D Seat Adjuster Switch - Driver X1

S64D Seat Adjuster Switch - Driver X2 (AJK)

**K40D** K40D Seat Memory Control Module - Driver (AAB)

Driver Seat Components

K40D Seat Memory Control Module - Driver X1 (AAB)

K40D Seat Memory Control Module - Driver X2 (AAB)

K40D Seat Memory Control Module - Driver X3 (AAB)

K40D Seat Memory Control Module - Driver X4 (AAB)

K40D Seat Memory Control Module - Driver X5 (AAB)

K40D Seat Memory Control Module - Driver X6 (AAB)

**Drivers Seat Lumbar (AJK)**

**CAV\_2** 2

**CAV\_10** 10

**CONN\_X3** X3

**611** Driver Seat Lumbar Support Motor Forward Control

**611\_L-BU** 611 L-BU

**CAV\_5** 5

**CAV\_9** 9

**5892** Driver Seat Bolster Motor Rearward Control

**5892\_YE/BN** 5892 YE/BN

**CAV\_1** 1

**CAV\_7** 7

**5891** Driver Seat Bolster Motor Forward Control

**5891\_YE/L-BU** 5891 YE/L-BU

**CAV\_3** 3

**CAV\_8** 8

**610\_VT** 610 VT

**611\_L-BU** 611 L-BU

**5892\_YE/RD** 5892 YE/RD

**5891\_YE/L-BU** 5891 YE/L-BU

**1065** Driver Seat Lumbar Support Forward Switch Signal

**1065\_YE** 1065 YE

**CAV\_14** 14

**CONN\_X5** X5

**1064** Driver Seat Lumbar Support Rearward Switch Signal

**1064\_L-BU/VT** 1064 L-BU/VT

**CAV\_15** 15

**CAV\_6** 6

**1067** Driver Seat Lumbar Support Down Switch Signal

**CAV\_17** 17