

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2009 NISSAN X-Trail (T31) OEM Service and Repair Workshop Manual

[Go to manual page](#)

Monitor item	Condition		Values / Status
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 77	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 76	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 75	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 74	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 73	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 72	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 71	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 70	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 69	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 68	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 67	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 66	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 65	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 64	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 63	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG

Monitor item	Condition		Values / Status
Cell condition 62	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 61	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 60	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 59	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 58	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 57	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 56	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 55	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 54	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 53	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 52	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 51	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 50	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 49	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 48	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 47	Power switch ON	Cell is normal	OK

Monitor item	Condition		Values / Status
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 46	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 45	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 44	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 43	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 42	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 41	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 40	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 39	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 38	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 37	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 36	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 35	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 34	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 33	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 32	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG

Monitor item	Condition		Values / Status
Cell condition 31	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 30	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 29	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 28	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 27	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 26	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 25	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 24	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 23	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 22	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 21	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 20	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 19	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 18	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 17	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 16	Power switch ON	Cell is normal	OK

Monitor item	Condition		Values / Status
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 15	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 14	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 13	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 12	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 11	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 10	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 09	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 08	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 07	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 06	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 05	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 04	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 03	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 02	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition 01	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG

Monitor item	Condition		Values / Status
Cell condition2 96	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 95	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 94	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 93	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 92	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 91	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 90	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 89	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 88	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 87	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 86	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 85	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 84	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 83	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 82	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 81	Power switch ON	Cell is normal	OK

Monitor item	Condition		Values / Status
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 80	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 79	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 78	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 77	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 76	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 75	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 74	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 73	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 72	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 71	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 70	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 69	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 68	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 67	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 66	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG

Monitor item	Condition		Values / Status
Cell condition2 65	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 64	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 63	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 62	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 61	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 60	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 59	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 58	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 57	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 56	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 55	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 54	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 53	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 52	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 51	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 50	Power switch ON	Cell is normal	OK

Monitor item	Condition		Values / Status
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 49	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 48	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 47	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 46	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 45	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 44	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 43	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 42	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 41	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 40	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 39	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 38	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 37	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 36	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG
Cell condition2 35	Power switch ON	Cell is normal	OK
		Cell malfunction is detected with cell diagnosis	NG