

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2017 Nissan Armada Service and Repair Manual

[Go to manual page](#)

- **With the detection of “U2343-87” some systems do not perform the fail-safe operation.**
- **A system controlling based on a signal received from the control unit performs fail-safe operation when the communication with the around view monitor control unit becomes inoperable.**

Sample

1. DTC CONFIRMATION PROCEDURE

1. Set the vehicle to READY and then wait for 2 seconds or more.
2. Perform “All DTC Reading” with CONSULT.
3. Check if the “U2343-87” is detected as the current malfunction in “Self Diagnostic Result” of “AROUND VIEW MONITOR”.

Is “U2343-87” detected as the current malfunction?

YES >>

Refer to [DTC Diagnosis Procedure](#).

NO-1 >>

To check malfunction symptom before repair: Refer to [Intermittent Incident](#).

NO-2 >>

Confirmation after repair: INSPECTION END

Sample

1. CHECK CAN DIAGNOSIS

Perform the trouble diagnosis for CAN communication system. Refer to [Trouble Diagnosis Flow Chart](#).

>>

INSPECTION END

Sample

DTC DETECTION LOGIC

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control units, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H, CAN-L) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads the required data only.

CAN communication signal chart. Refer to [CAN Communication Signal Chart](#).

DTC		CONSULT screen terms	DTC detection condition	
U2348	87	CAN comm err (brake control unit)	Diagnosis condition	When vehicle is READY
			Signal (terminal)	CAN communication signal
			Threshold	If around view monitor control unit is not transmitting or receiving CAN communication signal
			Diagnosis delay time	2 seconds or more



NOTE:

If “U2348-87” is detected, first diagnose the CAN communication system.

POSSIBLE CAUSE

CAN communication system

FAIL-SAFE

The following systems are canceled.

- Vehicle speed & vehicle-to-vehicle control function
- Lane keep function*1
- Lane keep function*2
- Lane change support function
- Overtaking support function
- Route driving support function
- AEB
- RAB
- I-FCW
- I-LI
- I-BSI
- TSR
- I-DA

*1: ProPILOT Assist 2.0 display is green



NOTE:

With the detection of “U2348-87” some systems do not perform the fail-safe operation. A system controlling based on a signal received from the control unit performs fail-safe operation when the communication with the ADAS control unit 2 becomes inoperable.

Sample

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Set the vehicle to READY, and then wait for 2 seconds or more.
2. Perform “All DTC Reading” with CONSULT.
3. Check if the “U2348-87” is detected as the current malfunction in “Self Diagnostic Result” of “AROUND VIEW MONITOR”.

Is “U2348-87” detected as the current malfunction?

YES >>

Refer to [DTC Diagnosis Procedure](#).

NO-1 >>

To check malfunction symptom before repair: Refer to [Intermittent Incident](#).

NO-2 >>

Confirmation after repair: INSPECTION END

Sample

1. CHECK CAN DIAGNOSIS

Perform the trouble diagnosis for CAN communication system. Refer to [Trouble Diagnosis Flow Chart](#).

>>

INSPECTION END

Sample

DTC DETECTION LOGIC

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control units, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H, CAN-L) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads the required data only.

CAN communication signal chart. Refer to [CAN Communication Signal Chart](#).

DTC		CONSULT screen terms	DTC detection condition	
U2350	87	CAN communication error(Air bag diagnosis sensor unit)	Diagnosis condition	Vehicle: READY
			Signal (terminal)	CAN communication signal
			Threshold	If around view monitor control unit is not transmitting or receiving CAN communication signal
			Diagnosis delay time	2 seconds or more



NOTE:

If "U2350-87" is detected, first diagnose the CAN communication system.

POSSIBLE CAUSE

CAN communication system

FAIL-SAFE

None

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Set the vehicle to READY and wait at least 2 seconds.
2. Perform “All DTC Reading” with CONSULT.
3. Check if the “U2350-87” is detected as the current malfunction in “Self Diagnostic Result” of “AROUND VIEW MONITOR”.

Is “U2350-87” detected as the current malfunction?

YES >>

Refer to [DTC Diagnosis Procedure](#).

NO-1 >>

To check malfunction symptom before repair: Refer to [Intermittent Incident](#).

NO-2 >>

Confirmation after repair: INSPECTION END

Sample