


Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2018 VOLVO V60 Polestar OEM Service and Repair Workshop Manual

[Go to manual page](#)




Courtesy of VOLVO CARS CORPORATION

Disconnect the connector.
Remove the marked part.

IMPACT SENSOR, B-PILLAR > IMPACT SENSOR, B-PILLAR [2018-2022] > INSTALLATION

To install, reverse the removal procedure.
Perform supplemental restraint system (SRS), post check. Refer to: SUPPLEMENTARY RESTRAINT SYSTEM

IMPACT SENSOR, C-PILLAR > IMPACT SENSOR, C-PILLAR [2018-2022] > REMOVAL



Courtesy of VOLVO CARS CORPORATION

NOTE: The graphic shows the back of the component before removal.



Courtesy of VOLVO CARS CORPORATION


Remove the marked part.

IMPACT SENSOR, C-PILLAR > IMPACT SENSOR, C-PILLAR [2018-2022] > INSTALLATION

To install, reverse the removal procedure.


Perform supplemental restraint system (SRS), post check. Refer to: SUPPLEMENTARY RESTRAINT SYSTEM

IMPACT SENSOR, FRONT > IMPACT SENSOR, FRONT [2021-2022, E400V6] > REMOVAL




NOTE: *Orientation view*

APPLIES TO THE RIGHT-HAND SIDE




Courtesy of VOLVO CARS CORPORATION

Disconnect the connector.




Courtesy of VOLVO CARS CORPORATION

Disconnect the connector.




Courtesy of VOLVO CARS CORPORATION

Torque: Entry handle, to bracket, 6Nm
Remove the screws.
On both sides.



Courtesy of VOLVO CARS CORPORATION



Courtesy of VOLVO CARS CORPORATION

Remove the marked part.