

# Your Ultimate Source for OEM Repair Manuals


FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

## 2021 Toyota RAV4 Prime Service and Repair Manual

[Go to manual page](#)

**HINT:**

Perform this procedure only when the lid has been opened.

**26. INSTALL QUARTER TRIM UPPER PANEL LH**

Click here [INFO](#) [INFO](#)

**27. INSTALL QUARTER TRIM UPPER PANEL RH****HINT:**

Use the same procedure as for the LH side.

**28. INSTALL CENTER PILLAR GARNISH ASSEMBLY LH**

Click here [INFO](#) [INFO](#)

**29. INSTALL CENTER PILLAR GARNISH ASSEMBLY RH****HINT:**

Use the same procedure as for the LH side.

**30. INSTALL TRANSVERSE PIPE**

Click here [INFO](#)

**31. INSTALL SEAT BELT HOLE COVER SUB-ASSEMBLY LH**

Click here [INFO](#) [INFO](#)

**32. REMOVE SEAT BELT HOLE COVER SUB-ASSEMBLY RH****HINT:**

Use the same procedure as for the LH side.

**33. INSTALL TRANSVERSE PIPE TRIM**

Click here [INFO](#)

**34. INSTALL ROOF SIDE INNER GARNISH ASSEMBLY LH**

Click here [INFO](#)

**35. INSTALL ROOF SIDE INNER GARNISH ASSEMBLY RH****HINT:**

Use the same procedure as for the LH side.


**36. INSTALL DECK BOARD ASSEMBLY**


(a) Slide the left edge of the deck board assembly (1) into the recess in the direction of the arrow of the deck board assembly.

<b>Last Modified:</b> 07-26-2024	6.11:8.1.0	<b>Doc ID:</b> RM100000001JCNU
<b>Model Year Start:</b> 2020	<b>Model:</b> Supra	<b>Prod Date Range:</b> [03/2019 - 07/2020]
<b>Title:</b> AUDIO / VIDEO: FRONT DOOR SPEAKER: COMPONENTS; 2020 - 2021 MY Supra [03/2019 - 07/2020]		

COMPONENTS

ILLUSTRATION



*A	w/ Courtesy Light	-	-
*1	COURTESY LIGHT ASSEMBLY	*2	FRONT DOOR TRIM BOARD SUB-ASSEMBLY
*3	FRONT NO. 1 SPEAKER ASSEMBLY	*4	FRONT NO. 2 SPEAKER ASSEMBLY
*5	DOOR TRIM COVER	*6	FRONT DOOR SPEAKER HOLE COVER
*7	NO. 2 DOOR INSIDE HANDLE BEZEL	-	-
	N*m (kgf*cm, ft.*lbf): Specified torque	-	-



<b>Last Modified:</b> 07-26-2024	6.11:8.1.0	<b>Doc ID:</b> RM100000001JCNV
<b>Model Year Start:</b> 2020	<b>Model:</b> Supra	<b>Prod Date Range:</b> [03/2019 - 07/2020]
<b>Title:</b> AUDIO / VIDEO: FRONT DOOR SPEAKER: REMOVAL; 2020 - 2021 MY Supra [03/2019 - 07/2020]		

## REMOVAL

## CAUTION / NOTICE / HINT

**HINT:**

- Use the same procedure for the RH side and LH side.
- The following procedure is for the LH side.

## PROCEDURE

**1. REMOVE COURTESY LIGHT ASSEMBLY (w/ Courtesy Light)**


Click here [INFO](#)

**2. REMOVE FRONT DOOR TRIM BOARD SUB-ASSEMBLY**

Click here [INFO](#)

**3. REMOVE FRONT NO. 1 SPEAKER ASSEMBLY**

(a) Unlock plug connection (1) and disconnect.



(b) Loosen T20 screws (2).

(c) Remove the front No. 1 speaker assembly (3).

**4. REMOVE FRONT NO. 2 SPEAKER ASSEMBLY**

(a) Detach the clamp (1).

<b>Last Modified:</b> 07-26-2024	6.11:8.1.0	<b>Doc ID:</b> RM100000001R9JT
<b>Model Year Start:</b> 2021	<b>Model:</b> Supra	<b>Prod Date Range:</b> [07/2020 -       ]
<b>Title:</b> AUDIO / VIDEO: FRONT DOOR SPEAKER: REMOVAL; 2021 - 2025 MY Supra [07/2020 -       ]		

## REMOVAL

## CAUTION / NOTICE / HINT

**HINT:**

- Use the same procedure for the RH side and LH side.
- The following procedure is for the LH side.

## PROCEDURE

### 1. REMOVE COURTESY LIGHT ASSEMBLY (w/ Courtesy Light)


Click here [INFO](#)

### 2. REMOVE FRONT DOOR TRIM BOARD SUB-ASSEMBLY

Click here [INFO](#)

### 3. REMOVE FRONT NO. 1 SPEAKER ASSEMBLY

(a) Unlock plug connection (1) and disconnect.



(b) Loosen T20 screws (2).

(c) Remove the front No. 1 speaker assembly (3).

### 4. REMOVE FRONT NO. 2 SPEAKER ASSEMBLY (w/ Front Center Speaker)

(a) Detach the clamp (1).