


Your Ultimate Source for OEM Repair Manuals


FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2022 Volvo S90 Service and Repair Manual

Go to manual page



Cut following the dotted lines. **Use:** Cutting pliers




NOTE: Make sure that a new component is installed.


- 1. Measure distance from rubber fixation to clips.
- 2. Adjust to the specified value.

Use: Tape measure

REPAIR

See information about splicing cables. Refer to: JOINING CABLES





Attach the insulation tape around the cable, as shown.

Use: Electrical tape, 9511028

Reinstall the removed parts in reverse order.

ANTI-LOCK BRAKE SYSTEM > ANTI-LOCK BRAKE SYSTEM (ABS) WIRING [2021-2022, E400V6] > REMOVAL AND INSTALLATION


REMOVAL

Perform battery disconnecting and connecting. Refer to: BATTERY DISCONNECTING AND CONNECTING


Remove relevant side front wheel. Refer to: WHEELS

Remove front wheel arch liner. Refer to: FRONT WHEEL ARCH LINER


APPLIES TO THE LEFT-HAND SIDE:




Remove the cable harness clips. Disconnect the connector.




Install the marked components. **Use:** Splice, 9130467



Adjust the position of the wiring. Install the clip(s).



Remove the cable harness clips.



NOTE: Thread the heat-shrinkable tubing onto the electrical wiring before splicing the electrical wiring.

Install the heat-shrinkable tubing. **Use:** heat-shrinkable tubing, 976422