

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2011 NISSAN 370Z Roadster OEM Service and Repair Workshop Manual

[Go to manual page](#)

DTC DETECTION LOGIC

DTC		CONSULT screen terms	DTC detecting condition	
P168D	11	System main relay	Diagnosis condition	Power switch ON (During system main relay 1 OFF command)
			Signal	System main relay 1 drive signal
			Threshold	A short to ground in system main relay 1 drive circuit is detected
			Detection time	—

POSSIBLE CAUSE

- Harness and connector (System main relay 1 circuit is shorted to ground)
- System main relay 1

FAIL-SAFE

Restart is prohibited

Sample

1. PRECONDITIONING

1. Press the power switch for at least 2 seconds to turn the high voltage system OFF and then check that the charging status indicator is not illuminated.

**NOTE:**

When the high voltage system is turned ON, the charging status indicator blinks green with a frequency of 1 second.

2. After the high voltage system is turned OFF, open the driver's side door, get out of the vehicle, close the driver's side door and wait for at least 5 minutes.

CAUTION:

- **Since the auto ACC function causes the accessory power to be turned ON, do not perform any vehicle operation including locking the doors or opening and closing of the doors during the standby state.**

If an operation is performed, wait an additional 5 minutes from that time.

- **Check that 12V battery voltage is 11 V or more.**

>>

[GO TO 2](#) .

2. PERFORM DTC CONFIRMATION PROCEDURE

 With CONSULT

1. Set the vehicle to READY and wait at least 10 seconds.
2. Check self-diagnostic result in “EV/HEV”.

Is DTC detected?

YES>>

Refer to [DTC Diagnosis Procedure](#).

NO-1>>

To check malfunction symptom before repair: Refer to [Intermittent Incident](#).

NO-2>>

Confirmation after repair: INSPECTION END

1. CHECK SYSTEM MAIN RELAY 1 GROUND CIRCUIT

Check system main relay 1 ground circuit. Refer to [Diagnosis Procedure](#).

Is the inspection result normal?

YES>>

[GO TO 2](#)

NO>>

Repair or replace error-detected parts, [GO TO 3](#).

2. CHECK SYSTEM MAIN RELAY 1 CIRCUIT

Check system main relay 1 circuit. Refer to [Diagnosis Procedure](#)(66kWh LI-ION BATTERY), [Diagnosis Procedure](#)(91kWh LI-ION BATTERY).

Is the inspection result normal?

YES>>

INSPECTION END

NO>>

Repair or replace error-detected parts, [GO TO 3](#).

3. PERFORM CONFIRMATION PROCEDURE AGAIN

1. Erase DTC.

2. Perform DTC confirmation procedure again. Refer to [Confirmation Procedure](#).

Is DTC P168D-11 detected again?

YES>>

Replace VCM. Refer to [VCM : Removal & Installation](#).

NO>>

INSPECTION END

DTC DETECTION LOGIC

DTC		CONSULT screen terms	DTC detecting condition	
P168D	12	System main relay	Diagnosis condition	READY (During system main relay 1 ON command)
			Signal	System main relay 1 drive signal
			Threshold	A short to power supply in system main relay 1 drive circuit is detected
			Detection time	—

POSSIBLE CAUSE

- Harness and connector (System main relay 1 circuit is shorted to power supply)
- System main relay 1

FAIL-SAFE

High-voltage system is normally stopped

1. PRECONDITIONING

1. Press the power switch for at least 2 seconds to turn the high voltage system OFF and then check that the charging status indicator is not illuminated.

**NOTE:**

When the high voltage system is turned ON, the charging status indicator blinks green with a frequency of 1 second.

2. After the high voltage system is turned OFF, open the driver's side door, get out of the vehicle, close the driver's side door and wait for at least 5 minutes.

CAUTION:

- **Since the auto ACC function causes the accessory power to be turned ON, do not perform any vehicle operation including locking the doors or opening and closing of the doors during the standby state.**

If an operation is performed, wait an additional 5 minutes from that time.

- **Check that 12V battery voltage is 11 V or more.**

>>

[GO TO 2](#) .

2. PERFORM DTC CONFIRMATION PROCEDURE

 With CONSULT

1. Set the vehicle to READY and wait at least 10 seconds.
2. Check self-diagnostic result in “EV/HEV”.

Is DTC detected?

YES>>

Refer to [DTC Diagnosis Procedure](#).

NO-1>>

To check malfunction symptom before repair: Refer to [Intermittent Incident](#).

NO-2>>

Confirmation after repair: INSPECTION END

1. CHECK SYSTEM MAIN RELAY 1 GROUND CIRCUIT

Check system main relay 1 ground circuit. Refer to [Diagnosis Procedure](#).

Is the inspection result normal?

YES>>

[GO TO 2](#)

NO>>

Repair or replace error-detected parts, [GO TO 3](#).

2. CHECK SYSTEM MAIN RELAY 1 CIRCUIT

Check system main relay 1 circuit. Refer to [Diagnosis Procedure](#)(66kWh LI-ION BATTERY), [Diagnosis Procedure](#)(91kWh LI-ION BATTERY).

Is the inspection result normal?

YES>>

INSPECTION END

NO>>

Repair or replace error-detected parts, [GO TO 3](#).

3. PERFORM CONFIRMATION PROCEDURE AGAIN

1. Erase DTC.

2. Perform DTC confirmation procedure again. Refer to [Confirmation Procedure](#).

Is DTC P168D-12 detected again?

YES>>

Replace VCM. Refer to [VCM : Removal & Installation](#).

NO>>

INSPECTION END

DTC DETECTION LOGIC

DTC		CONSULT screen terms	DTC detecting condition	
P168D	13	System main relay	Diagnosis condition	Power switch ON (During system main relay 1 OFF command)
			Signal	System main relay 1 drive signal
			Threshold	An opening in system main relay 1 drive circuit is detected
			Detection time	—

POSSIBLE CAUSE

- Harness and connector (System main relay 1 circuit is open)
- System main relay 1

FAIL-SAFE

High-voltage system is normally stopped

1. PRECONDITIONING

1. Press the power switch for at least 2 seconds to turn the high voltage system OFF and then check that the charging status indicator is not illuminated.

**NOTE:**

When the high voltage system is turned ON, the charging status indicator blinks green with a frequency of 1 second.

2. After the high voltage system is turned OFF, open the driver's side door, get out of the vehicle, close the driver's side door and wait for at least 5 minutes.

CAUTION:

- **Since the auto ACC function causes the accessory power to be turned ON, do not perform any vehicle operation including locking the doors or opening and closing of the doors during the standby state.**

If an operation is performed, wait an additional 5 minutes from that time.

- **Check that 12V battery voltage is 11 V or more.**

>>

[GO TO 2](#) .

2. PERFORM DTC CONFIRMATION PROCEDURE

 With CONSULT

1. Set the vehicle to READY and wait at least 10 seconds.
2. Check self-diagnostic result in “EV/HEV”.

Is DTC detected?

YES>>

Refer to [DTC Diagnosis Procedure](#).

NO-1>>

To check malfunction symptom before repair: Refer to [Intermittent Incident](#).

NO-2>>

Confirmation after repair: INSPECTION END

1. CHECK SYSTEM MAIN RELAY 1 GROUND CIRCUIT

Check system main relay 1 ground circuit. Refer to [Diagnosis Procedure](#).

Is the inspection result normal?

YES>>

[GO TO 2](#)

NO>>

Repair or replace error-detected parts, [GO TO 3](#).

2. CHECK SYSTEM MAIN RELAY 1 CIRCUIT

Check system main relay 1 circuit. Refer to [Diagnosis Procedure](#)(66kWh LI-ION BATTERY), [Diagnosis Procedure](#)(91kWh LI-ION BATTERY).

Is the inspection result normal?

YES>>

INSPECTION END

NO>>

Repair or replace error-detected parts, [GO TO 3](#).

3. PERFORM CONFIRMATION PROCEDURE AGAIN

1. Erase DTC.

2. Perform DTC confirmation procedure again. Refer to [Confirmation Procedure](#).

Is DTC P168D-13 detected again?

YES>>

Replace VCM. Refer to [VCM : Removal & Installation](#).

NO>>

INSPECTION END