

# Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

## 2020 NISSAN NV200 Service and Repair Manual

[Go to manual page](#)

## DTC DETECTION LOGIC

DTC		CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	
C1F48	04	ABS/TCS/VDC CIRC (Anti-lock braking system/Traction control system/Vehicle dynamics control system circuit)	Diagnosis condition	<ul style="list-style-type: none"> <li>When vehicle is READY</li> <li>When AEB system is ON</li> </ul>
			Signal (terminal)	VDC/TCS/ABS malfunction signal
			Threshold	If a malfunction occurs in the VDC/TCS/ABS system
			Diagnosis delay time	1 second or less

## POSSIBLE CAUSE

- ABS actuator and electric unit (control unit)
- ADAS control unit 2

## FAIL-SAFE

The following systems are canceled.

- Vehicle-to-vehicle distance control mode
- Conventional (fixed speed) cruise control mode
- Steering wheel assistance function
- AEB
- RAB
- I-FCW
- I-LI
- I-BSI
- TSR

## CONFIRMATION PROCEDURE

### 1. CHECK DTC PRIORITY

If DTC "C1F48-04" is displayed with Network-DTC, first diagnose the Network-DTC.

Is applicable DTC detected?

YES >>

Perform diagnosis of applicable. Refer to [DTC Index](#).

NO >>

[GO TO 2.](#)

## 2. PERFORM DTC CONFIRMATION PROCEDURE

---

1. Set the vehicle to READY.
2. Turn the AEB system ON.
3. Perform “All DTC Reading” with CONSULT.
4. Check if the “C1F48-04” is detected as the current malfunction in “Self Diagnostic Result” of “ICC/ADAS 2”.

Is “C1F48-04” detected as the current malfunction?

YES >>

Refer to [DTC Diagnosis Procedure](#).

NO-1 >>

To check malfunction symptom before repair: Refer to [Intermittent Incident](#).

NO-2 >>

Confirmation after repair: INSPECTION END

Sample

## DTC DETECTION LOGIC

DTC		CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	
C1F48	29	ABS/TCS/VDC CIRC (Anti-lock braking system/Traction control system/Vehicle dynamics control system circuit)	Diagnosis condition	<ul style="list-style-type: none"> <li>When vehicle is READY</li> <li>When AEB system is ON</li> </ul>
			Signal (terminal)	Wheel speed signal
			Threshold	Wheel speed signal from ABS actuator and electric unit (control unit) is malfunction
			Diagnosis delay time	1 second or less

## POSSIBLE CAUSE

- ABS actuator and electric unit (control unit)
- ADAS control unit 2

## FAIL-SAFE

The following system are cancelled.

- Vehicle speed & vehicle-to-vehicle control function
- Lane keep function\*<sup>1</sup>
- Lane keep function\*<sup>2</sup>
- Lane change support function
- Overtaking support function
- Route driving support function
- AEB
- RAB
- I-FCW
- I-LI
- I-BSI
- TSR

\*1: ProPILOT Assist 2.0 display is green

\*2: ProPILOT Assist 2.0 display is blue

## CONFIRMATION PROCEDURE

### 1. CHECK DTC PRIORITY

If DTC “C1F48-29” is displayed with Network-DTC, first diagnose the Network-DTC.

Is applicable DTC detected?

YES>>

Perform diagnosis of applicable. Refer to [DTC Index](#).

NO>>

[GO TO 2.](#)

## **2. PERFORM DTC CONFIRMATION PROCEDURE**

---

1. Set the vehicle to READY.
2. Turn the AEB system ON.
3. Perform “All DTC Reading” with CONSULT.
4. Check if the “C1F48-29” is detected as the current malfunction in “Self Diagnostic Result” of “ICC/ADAS 2”.

Is “C1F48-29” detected as the current malfunction?

YES>>

Refer to [DTC Diagnosis Procedure](#).

NO-1>>

To check malfunction symptom before repair: Refer to [Intermittent Incident](#).

NO-2>>

Confirmation after repair: INSPECTION END

## 1. CHECK DTC PRIORITY

---

If DTC “C1F48-29” is displayed with Network-DTC, first diagnose the Network-DTC.

Is applicable DTC detected?

YES>>

Perform diagnosis of applicable. Refer to [DTC Index](#).

NO>>

[GO TO 2.](#)

## 2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

---

Check if any DTC is detected in “Self Diagnostic Result” of “ABS”.

Is any DTC detected?

YES>>

Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [DTC Index](#).

NO>>

Replace the ADAS control unit 2. Refer to [Removal and Installation](#).

## DTC DETECTION LOGIC

DTC		CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	
C1F48	82	ABS/TCS/VDC CIRC (Anti-lock braking system/Traction control system/Vehicle dynamics control system circuit)	Diagnosis condition	<ul style="list-style-type: none"> <li>When vehicle is READY</li> <li>When AEB system is ON</li> </ul>
			Signal (terminal)	—
			Threshold	If ADAS control unit 2 detects an error signal that is received from ABS actuator and electric unit (control unit) via CAN communication
			Diagnosis delay time	1 second or less

## POSSIBLE CAUSE

- ABS actuator and electric unit (control unit)
- ADAS control unit 2

## FAIL-SAFE

The following systems are canceled.

- Vehicle speed & vehicle-to-vehicle control function
- Lane keep function\*1
- Lane keep function\*2
- Lane change support function
- Overtaking support function
- Route driving support function
- AEB
- RAB
- I-FCW
- I-LI
- I-BSI
- TSR

\*1: ProPILOT Assist 2.0 display is green

\*2: ProPILOT Assist 2.0 display is blue

## CONFIRMATION PROCEDURE

### 1. CHECK DTC PRIORITY

If DTC “C1F48–82” is displayed with Network-DTC, first diagnose the Network-DTC.

Is applicable DTC detected?

YES >>

Perform diagnosis of applicable. Refer to [DTC Index](#).

NO >>

[GO TO 2.](#)

## **2. PERFORM DTC CONFIRMATION PROCEDURE**

---

1. Set the vehicle to READY.
2. Turn the AEB system ON.
3. Perform “All DTC Reading” with CONSULT.
4. Check if the “C1F48–82” is detected as the current malfunction in “Self Diagnostic Result” of “ICC/ADAS 2”.

Is “C1F48-82” detected as the current malfunction?

YES >>

Refer to [DTC Diagnosis Procedure](#).

NO-1 >>

To check malfunction symptom before repair: Refer to [Intermittent Incident](#).

NO-2 >>

Confirmation after repair: INSPECTION END



## 1. CHECK DTC PRIORITY

---

If DTC “C1F48–82” is displayed with Network-DTC, first diagnose the Network-DTC.

Is applicable DTC detected?

YES >>

Perform diagnosis of applicable. Refer to [DTC Index](#) (Without ProPILOT Assist 2.0) or [DTC Index](#) (With ProPILOT Assist 2.0).

NO >>

[GO TO 2.](#)

## 2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

---

Check if any DTC is detected in “Self Diagnostic Result” of “ABS”.

Is any DTC detected?

YES >>

Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [DTC Index](#).

NO >>

Replace the ADAS control unit 2. Refer to [Removal and Installation](#) (Without ProPILOT Assist 2.0) or [Removal and Installation](#) (With ProPILOT Assist 2.0).

## DTC DETECTION LOGIC

DTC		CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	
C1F48	82	ABS/TCS/VDC CIRC (Anti-lock braking system/Traction control system/Vehicle dynamics control system circuit)	Diagnosis condition	<ul style="list-style-type: none"> <li>When vehicle is READY</li> <li>When AEB system is ON</li> </ul>
			Signal (terminal)	—
			Threshold	If ADAS control unit 2 detects an error signal that is received from ABS actuator and electric unit (control unit) via CAN communication
			Diagnosis delay time	1 second or less

## POSSIBLE CAUSE

- ABS actuator and electric unit (control unit)
- ADAS control unit 2

## FAIL-SAFE

The following systems are canceled.

- Vehicle-to-vehicle distance control mode
- Conventional (fixed speed) cruise control mode
- Steering wheel assistance function
- AEB
- RAB
- I-FCW
- I-LI
- I-BSI
- TSR

## CONFIRMATION PROCEDURE

### 1. CHECK DTC PRIORITY

If DTC “C1F48-82” is displayed with Network-DTC, first diagnose the Network-DTC.

Is applicable DTC detected?

YES >>

Perform diagnosis of applicable. Refer to [DTC Index](#).

NO >>