


# Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.


## 2013 JEEP Grand Cherokee SRT OEM Service and Repair Workshop Manual

[Go to manual page](#)



0903190135

CALLOUT	DESCRIPTION	SPECIFICATION	COMMENT
1	Heat Shield Nuts - Plastic	5 N·m (44 In. Lbs.)	-
2	Heat Shield Bolts	18 N·m (13 Ft. Lbs.)	-
3	Heat Shield Nuts - Steel	8 N·m (71 In. Lbs.)	-
-	Spare Tire Heat Shield To Underbody (Heat Shield Bolts)	6 N·m (53 In. Lbs.)	-




1 - Left Exhaust Muffler Clamp Nut
2 - Exhaust Isolator Bolt
3 - Right Exhaust Muffler Clamp Nut
4 - Exhaust Isolator Bolt

5. Loosen the right exhaust muffler clamp nut.

6. Remove the exhaust isolator bolts and lower the resonator.


7. Disconnect the oxygen sensor wire harness connectors.





0903190137

CALLOUT	DESCRIPTION	SPECIFICATION	COMMENT
1	Exhaust Isolator Bolts	<b>25 N·m (18 Ft. Lbs.)</b>	-
2	Torca Clamp Nut	<b>48 N·m (35 Ft. Lbs.)</b>	-



1 - Outer Bolts

2 - Inner Bolts


3 - Impact Brace

3. Remove the impact bracket inner bolts, outer bolts, and the impact bracket.




- Start the engine and inspect for exhaust leaks. Repair exhaust leaks as necessary.

## TORQUE SPECIFICATION - EXHAUST SYSTEM - 5.7L



0903190133


CALLOUT	DESCRIPTION	SPECIFICATION	COMMENT
1	Catalytic Converter To Manifold Bolts	<b>30 N·m (22 Ft. Lbs.)</b>	-
2	Exhaust Manifold Heat Shield Nuts	<b>10 N·m (7 Ft. Lbs.)</b>	-
3	Exhaust Manifold Bolts	<b>25 N·m (18 Ft. Lbs.)</b>	Tightening Sequence - Left Manifold



0903190135

CALLOUT	DESCRIPTION	SPECIFICATION	COMMENT
1	Heat Shield Nuts - Plastic	5 N·m (44 In. Lbs.)	-
2	Heat Shield Bolts	18 N·m (13 Ft. Lbs.)	-
3	Heat Shield Nuts - Steel	8 N·m (71 In. Lbs.)	-
-	Spare Tire Heat Shield To Underbody (Heat Shield Bolts)	6 N·m (53 In. Lbs.)	-






1 - Left Exhaust Muffler Clamp Nut
2 - Exhaust Isolator Bolt
3 - Right Exhaust Muffler Clamp Nut
4 - Exhaust Isolator Bolt

5. Loosen the right exhaust muffler clamp nut.

6. Remove the exhaust isolator bolts and lower the resonator.

7. Disconnect the oxygen sensor wire harness connectors.






0903190137

CALLOUT	DESCRIPTION	SPECIFICATION	COMMENT
1	Exhaust Isolator Bolts	<b>25 N·m (18 Ft. Lbs.)</b>	-
2	Torca Clamp Nut	<b>48 N·m (35 Ft. Lbs.)</b>	-

5 - EXHAUST ISOLATORS

11 - EXHAUST ISOLATORS

6 - EXHAUST ISOLATORS



1101195327

SHORT WHEEL BASE

1 - RIGHT CATALYTIC CONVERTER

7 - EXHAUST MUFFLER/RESONATOR

2 - LEFT CATALYTIC CONVERTER

8 - EXHAUST ISOLATORS

3 - EXHAUST CLAMP

9 - EXHAUST ISOLATORS

4 - EXHAUST CLAMP

10 - EXHAUST ISOLATORS

5 - EXHAUST ISOLATORS

11 - EXHAUST ISOLATORS

6 - EXHAUST ISOLATORS

**WARNING**